



Easy Bake

PLASTIC



INSTRUCTIONS FOR USE

Ideal to serve your sweets and savouries.

1. Keep away from heat sources.
2. Do not wash in the dishwasher.

TECHNICAL DATA

Material	Plastic
Colour	white gold

USES AND PROHIBITIONS

